



# Quick Reference Guide

## DMP 7800



### Arm

1. Tap the shield icon in the center of the screen.
2. Select **“Arm”** on the left side of the screen.
3. Enter your **4-digit user code**.
4. Tap **“CMD”** in the bottom right corner.
5. To Arm all areas, tap **“Arm All”**. To selectively arm areas, select the desired areas, then tap **“Arm Selected.”**
6. The Exit Timer will display on the keypad, exit the building. If you need to cancel arming, tap the **“Enter Code to Cancel”** box, enter your 4-digit code then **“CMD”**.

### Disarm

**\*If entering an Armed building/area and the entry delay is in progress, skip to step 3.**

1. Tap the shield icon in the center of the screen.
2. Select **“Disarm”**.
3. Enter your **4-digit user code** then **“CMD”**.
4. To Disarm all areas, tap **“Disarm All”**. To selectively disarm areas, select the desired areas, then tap **“Disarm Selected.”**

### Clearing an Alarm

1. Enter your **4-digit user code** then **“CMD”**.
2. Screen will ask, **“False Alarm?”** — Select **“Yes”**.
3. From the Home Screen, select the yellow **“Attention List”** to display alarms. If there are no further issues with the system, the message will disappear after viewing.
4. If there is still an alarm message displaying, follow steps for Disarming.

## Viewing System/Sensor Status

If any sensors are in Trouble, a yellow “**Attention List!**” banner will appear above the shield on the Main Screen. Tap this banner to view the list of issues.

If any sensors are open, this will display when attempting to Arm the system. The screen will show a list of currently open sensors. You will then be given the choice to continue arming (**OK**), Bypass any open sensors (**Bypass**), or Stop arming (**Stop Arming**). Unless there is a known issue with a sensor, it is recommended to choose **Stop Arming** and verify the sensor is closed before trying to Arm again.

## Bypassing Zones

### Method 1:

1. On the main screen, tap “**Bypass**” to the right of the shield (scroll if needed).
2. Enter your **4-digit user code** and tap “**CMD**”.
3. Enter the **zone number** and tap “**BYP**” to bypass that zone.
4. To restore a bypassed zone, repeat steps 1-3, but tap “**RST**” instead of “**BYP**”.
5. Zone Bypassing will only last for One arming cycle – Once the system has been Armed, the bypass will clear upon being Disarmed again, and the bypass will have to be repeated.

### Method 2:

1. Begin the Arming procedure by tapping the shield and selecting Arm.
2. After selecting the area to Arm or selecting Arm All, a list of open sensors will be displayed.
3. To bypass all open sensors, tap “**Bypass**”.

## Enable/Disable Door Chime

From the Home Screen, scroll down the list on the right and press “Chime”. If the chime feature is enabled, there will be an icon in the top right corner showing an open door. If the chime feature is off, the icon will disappear.

## Adjusting the Keypad Volume/Brightness

1. From the Home Screen, scroll down the list on the right and press “Options”.
2. Adjust the Brightness/Volume/Tone sliders to preferred setting by using + or -.
3. Press the **Shield** icon at top right to return to the Home Screen.

**\*To adjust Code/Profiles/Schedules, please utilize the Virtual Keypad App or Webpage.**



1661 Greenview Dr. SW  
Rochester, MN 55902



Scan to view our Resources page.

Follow us for the latest products, safety tips, and Custom Alarm news.



507.288.5522 | [custom-alarm.com](https://www.custom-alarm.com)